



# Samsung SGH-A737 Screen Replacement

Written By: Tommy

## Step 1 — Screen



- Remove battery from the back of the device.

## Step 2



- Use a Phillips head screw driver to unscrew six screws on back on the device.

## Step 3



- Using the same screw driver, slide up the screen and remove two more screws beside the camera.

## Step 4



- Remove side buttons and pop out circuit board, this will expose two more screws. Remove these and keep them separate from the rest.

## Step 5



- Remove the Samsung sticker to expose two metal tabs.

## Step 6



- Peel off the black strip to expose two screws. Remove these.

## Step 7



- Use a Phillips head screwdriver to remove the four screws on the back of the screen.

## Step 8



- Once you have exposed the circuit board, peel off the green tape at the bottom. This will allow the removal of the screen.

## Step 9



- Before removing the screen, disconnect the orange tape at the top of the circuit board. You can do this by opening up the small lock.
- With the lock opened, the circuit board will automatically detach when you pull it out in step 11.

## Step 10



- Use a flathead screwdriver to reach under the circuit board and pry it up. You should hear a tearing sound; this is the glue separating from the screen.

## Step 11



- Once you have pried it up, the screen should come out easily. The camera and its microphone are attached at the top(outlined in red).
- With the screen removed, you can then put the new one in. You must attach the orange strip to the new circuit board to properly install it.

---

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-24 02:03:40 PM.